

HEALTHIER HOMES

QUICK SPECS CHEAT SHEET



- new drywall
New Construction Primer (1c @300-350 sq ft/gal)
Real Zero VOC Paint; flat or semigloss (2c @ 300-400 sq ft/gal)
- previously painted walls with water or oil based paint
Reno + Remodel Primer (1c @300-350 sq ft/gal)
Real Zero VOC Paint; flat or semigloss (2c @ 300-400 sq ft/gal)
- new unfinished doors and trim, to be painted
Reno + Remodel Primer (1c @300-350 sq ft/gal)
Real Zero VOC Paint; flat or semigloss (2c @ 300-400 sq ft/gal)
- previously painted woodwork and trim, to be painted
Reno + Remodel Primer (1c @300-350 sq ft/gal)
Real Zero VOC Paint; flat or semigloss (2c @ 300-400 sq ft/gal)
- new or re-sanded woodwork, with a clear finish topcoat
matte finish: **Cleary Natural Matte 3 coats** (3c @350 sq ft/gal)
gloss finish: **Cleary Natural Gloss 3 coats** (3c @350 sq ft/gal)
- wood furniture, wood cabinetry or shelving, to be painted
Reno + Remodel Primer (1c @300-350 sq ft/gal)
Furniture + Cabinet Lacquer; matte or gloss (3c @ 300-400 sq ft/gal with 311 tip and filters removed)
- sealing OSB, framing lumber, particle board, plywood and foam
Fumes + Formaldehyde Blocker (1c @ 350 sq/ft/gal; backpack sprayer, pump sprayer or spray bottle)
- integrated grout sealer
Fumes + Formaldehyde Blocker (mix ratio 1:1 blocker to distilled water per grout instructions)
- everyday cleaning
Healthier Clean concentrate (mix ratio 1:20 concentrate to warm water)
- degreaser and construction clean up
Healthier Clean concentrate (mix ratio 1:7 concentrate to warm water)
- laundry booster
Healthier Clean concentrate (1/4 cup in addition to your natural / clear detergent of choice per load)
- spot fixer for fabric stains
Healthier Clean concentrate (2 tbsp in water squirt bottle mixed with clean water)
- upholstery and carpet cleaner
Healthier Clean concentrate (mix ratio 1:20 concentrate to warm water)
- hand soap
Healthier Clean concentrate (3 tbsp in dispenser with water)